

APPENDIX I**ZM PARTS CHECKLIST**

(part numbers in brackets refer to assembly parts on pages 11 -13)

Page 1:	Column (16), Top bearing assembly (9), Dust hose attachment (23).
Page 2:	Belt clamps and plates (21), Carriage and turntable (10), C Section brace (4), T shaped support (3).
Page 3:	Pulley bearing support (17), Rod restraining bracket (18), Hooked material bracket (19), Bottom/Central hooked rail (15).
Page 4:	Centre Brace (6), Diagonal (14), Left hand frame/end stop (13), Foot (1).
Page 5:	Back leg (2), Front frame member (5), Knife edge (8), Top and bottom rail (7).
Page 6:	Central foot (28), Tie Rods (24), MDF backing panels(25).
Page 7:	Tapes, MDF Stand-offs (26), Belts (22), Bungee cord.
Page 8:	Fixings and Quantities: ZM12, ZM16.
Page 9:	Fixings and Quantities: ZM21, ZM21 Remote operating controls Manual

APPENDIX II

EXPLODED PARTS DIAGRAMS

- (a) Zapkut ZM 12 Assembly diagram
- (b) Zapkut ZM16 Assembly diagram
- (c) Zapkut ZM21 Assembly diagram *(not yet included)*

APPENDIX III

ADDITIONAL DIAGRAMS FOR ZM21 ONLY

- (a) ZM21 Electrical Control Box
- (b) ZM21 Remote Operating Handles:
 - Remote Plunge Arm
 - Foot Pedal Lock